

WARRANTY INFORMATION

Ultimate Support Systems offers a Limited Lifetime Warranty on Ulti-Boom Series. For Full Details, Exclusions and Limitations as well as information on Obtaining Warranty Service, please see full warranty details available online at www.ultimatesupport.com.

To purchase the Ultimate Protection Plus Premium Service and Support Plan, please visit www.ultimatesupport.com or call customer support at **800-525-5628** for more information.

WARRANTY REGISTRATION

Visit www.ultimatesupport.com for a quick and convenient process for registering your new Ultimate Support product. Warranty Registration and Proof of Purchase are required for warranty fulfillment. Full Limited Lifetime Warranty and Ultimate Protection Plus Premium Service and Support Plan details are available online.

ULTIMATE SUPPORT™

THE STRENGTH OF INNOVATION



Product Manual
for Ultimate Support

**ULTI-BOOM
SERIES**

ULTI-BOOM-TB
ITEM #17203



ULTI-BOOM-FB
ITEM #17202





SET-UP

ULTI-BOOM-TB (Telescoping)



ULTI-BOOM-FB (Fixed)



STEP 1
Attach ULTI Boom to mic stand.



STEP 2
Loosen the oversized rotation hub to adjust boom angle up or down, then tighten oversized rotation hub.




STEP 3
Lessen the ergonomic knobs to adjust boom length, then tighten ergonomic knobs.


SET-UP

ULTI-BOOM-TB & ULTI-BOOM-FB (Telescoping)

(Fixed)




STEP 4 Universal Mic Attachment
To adjust US to metric, use tool provided or 1.5 Allen Wrench to unlock threads. Turn US threads counter clockwise until it is removed. US MIC-Lock will come off too.



STEP 5 Universal Mic Attachment
After choosing desired thread, place microphone on universal mic attachment. Then turn MIC-Lock counter clockwise to lock mic in place.

WORKING PARTS

ULTI-BOOM-TB (Telescoping) ITEM #17203



ULTI-BOOM-FB (Fixed) ITEM #17202

