




ULTIMATE SUPPORT™

THE STRENGTH OF INNOVATION

IQ ACCESSORY

2ND TIER FOR IQ-1000 AND IQ-2000



IQ-2000 SHOWING

IQ-200 expands your IQ-2000 & IQ-1000
X-Stand to hold 2 keyboards





FEATURES OF IQ-200

Additional Tier - Easily add a 2ND keyboard or additional gear to IQ-2000 and IQ-1000 X-Style Keyboard Stands.

Width Adjustable - Accommodates a variety of gear.

Limited Lifetime Warranty - Constructed of the finest materials and backed by our award-winning customer support. For full details, exclusions and limitations as well as information on obtaining warranty service, visit www.ultimatesupport.com.

INSTRUCTIONS FOR ATTACHING ACCESSORY

1. Open IQ-1000 or IQ-2000 keyboard stand.
2. Remove friction sleeves and replace with shorter sleeves included in the Second Tier Packet. If you have a difficult time sliding the shorter sleeves into place, try using soapy water as a lubricant.
3. Using a screw driver or another blunt tool, remove end plugs from the tube.
4. Install hand knob, washer, and hex nut. It is important to place the hand knob on the inside or stand will not fold fully. Also, be careful not to over-tighten the hand knobs as repeated over-tightening may cause cracking of the collar.
5. Slide Second Tier assembly fully onto IQ Stand tube so IQ Stand tube end is visible in slot of collar. It may be necessary to remove weld from the inside of the IQ Stand tube using a file or chisel.
6. To fold the stand, loosen hand knobs and rotate Second Tier outward 180°. Hand knob can then be tightened for storage.

Visit www.ultimatesupport.com to download a detailed product manual, read full warranty details and to register your warranty.

SPECS OF IQ-200

- Item #13360—black
- Width adjustable
- Load capacity 50 lbs. (22.7 kg) distributed